

How to Install Guard Add-Ons

1. Set front guard in place.



2. Install the left and right add-ons to the rear mount of the front guard using 5/16"-18 X 2" hex head bolts (1 per add-on).



3. Finish the installation of the front guard by installing the front mounting bolts.

4. Installation is complete.