



**QUANTUM EDGE 2.0 & 3.0 FRONT GUARD (PN5173)
MOUNTING INSTRUCTIONS**



INSTALL BOLTS HERE



<---5/16-18x1 1/2 with 2 flat washers & half locknut

<---5/16-18x1 bolt with lockwasher



Bolt stradle front tie down loop--->

